

# In order to take advantage of the full "total installed cost" benefits of Watco *QuickTrim*<sup>™</sup> Kits, we recommend the following:

- 1. Purchase and install chrome Rough-In (RI) kits on all initial installations.
- 2. Purchase chrome Stopper/Faceplate (SF) kits for all chrome trim finishes.
- 3. Purchase kits for all special finish upgrades.
- 4. Purchase chrome **QuickTrim™** strainer body covers for repair of chrome strainer bodies that have been damaged during rough-in.



For More Information Contact: WATCO Manufacturing Company 1220 South Powell Road Independence, MO 64057-2724 Ph. 816-796-3900 • FAX 816-796-0875 www.watcomfg.com





## **SPECIFICATIONS**

#### FEATURES AND BENEFITS:

- No tools needed!
- Install chrome on the rough-in and easily upgrade to a special finish without removing the strainer body.
- Quickly and easily replace a damaged strainer body.
- Looks just as good as the original strainer body.
- Cover is thinner than a standard strainer body (.03") and will not create a water dam.
- The o-ring seal is all that is required; no silicone, plumber's putty, or epoxy is needed.
- Eliminates destroying the integrity of your test when removing a strainer body.
- Eliminates the labor required to remove and replace the strainer body.
- Eliminates the possibility of cross-threading or damaging the tub or of the drain fitting moving out of line when replacing the strainer body.

### PATENTS:

• U.S. Patent No. 4,720,877; 5,758,368; 7,503,083 B2; Patents Pending

#### Tub Closures: PUSH PULL® LIFT & TURN **PRESFLO®** FOOT ACT. CP - Chrome Plated • . . AB - Antique Brass • • AP - Aged Pewter • • BB - Brushed Bronze BN - Brushed Nickel . • BO - Bone • • BS - Biscuit • BZ - Oil-Rubbed Bronze • • • CB - Chrome Brushed • NP - Nickel Polished • • PB - Polished Brass • • PN - Pearl Nickel • • WH - White • • WI - Wrought Iron • .

# Finishes Available in the *QuickTrim*<sup>™</sup> Series:

© 2009 WATCO Mfg. Co.