

Accessories Pre-installation kit # 005072



Pre-installation kit	Dimension	Weight	Order number
in combination with SensoWash, for in-wall carrier with horizontal support without shower toilet pre-installation/conduit pipe			
Colors			
Variant			
Infobox			
# 005072 necessary during bare brickwork			

All drawings contain the necessary measurements which are subject to standard tolerances. They are stated in mm and are non-binding. Exact measurements, in particular for customised installation scenarios, can only be taken from the finished ceramic piece.