



---

**710-100, 710-101, 710-102, 710-103**  
**WOVEN POLYPROPYLENE DUCT STRAP**  
U.L. Listed



**Installation Recommendations\***

To install strap first determine and mark primary locations for duct support. Straps should be located close enough as to prevent duct sagging or as specified by local building code requirements.

Attach one side of strap to supporting joist by folding over the end of the strap 3"-4" and securing it with either a #8 screw or a minimum 3/8" staple. Additional screws or staples may be added if desired.

Wrap strap under ductwork creating a "cradle" for it to rest in. For even greater stability you may wrap ductwork completely around once. Check with your local building codes to insure this is an allowable procedure in your area.

Duct should be seated securely in strap. Do not pull strap so taught that it creates excess tension on the ductwork.

Secure second side of strap in the same fashion as first side and then cut free from roll.

\*These installation instructions are only a recommendation and in no way supersede local or state building codes. Please be sure to consult you local codes to insure proper installation for your area.