

HOW TO PROPERLY ORDER PARTS: In addition to part description and part number, please give model number, and type of gas used. This information can be found on the rating plate that is attached to rear of heater.

MODEL NUMBER	NAT. L.P.	VC201A-R VC202A-R	VC351,VCR351A-R VC352,VCR352A-R	VC501,VCR501A-R VC502,VCR502A-R	VC701,VCR701A-R VC702,VCR702A-R
PART DESCRIPTION	REF. NO.	PART NO.	PART NO.	PART NO.	PART NO.
Valve, 7000ASTR-4, Nat. Gas	1	84090	84090	84090	84090
Valve, 7000ASTR-4, L.P. Gas	1	80088	80088	80088	80088
Pilot Assy. 0.140.504 L.P.Gas	2	80063	80063	80063	80063
Pilot Assy. 0.140.514 Nat.Gas	2	80062	80062	80062	80062
Manifold	3	80110	80111	80113	80112
Orifice Nut	4	80024	80024	80024	80024
Burner Orifice, Natural Gas	5	80025	80058	80119	80169
Burner Orifice, L.P. Gas	5	80027	80060	80120	80167
Pilot Lighting Hole Cover	9	45332	45332	45332	45332
Thermocouple	10	70096	70096	70096	70096
Pilot Tubing Assy. w/Fittings	11	70012	70012	70012	70012
Vent Safety Spill Switch/ VC	12	80103	80104	80104	80099
Vent Safety Spill Switch/ VCR	12	N/A	80100	80102	80099
Wiring Harness w/Bluebird	13	80190	N/A	N/A	N/A
Wiring Harness w/ECO Fitting	13	N/A	80194	80194	80195
Control Rod	15	45375	45850	45850	47360
Control Rod Grommet	16	80010	80010	80010	80010
Temperature Control Knob	17	80318	80318	80318	80318
Burner, Steel	18	80123	80124	80125	80126
Burner Mounting Plate Assy.	19	45817	45817	45817	45817
Casing Door	20	45125	45605	46445	46445
Casing Door Latch	21	80005	80005	80005	80005
Casing Door Knob	22	N/A	80055	80055	80055
Casing Left Side, w/Insulation	23	45102	45590	46430	47140
Casing Right Side w/Insulation	24	45112	45600	46440	47150
Casing, Back Assembly	25	45150	45615	45615	47160
Casing, Top Assy. w/Insulation	26	45050	45550	46400	47100
"VC" Casing Front with/Insulation	28	45070	45560	45560	47110
"VC" Casing Trim Top & Sides	28a	45073	45563	45563	47113
"VC" Casing Bottom Trim	28b	45074	45564	45564	47114
"VC" Casing Center Trim w/Clips	28c	45077	45567	45567	47117
"VCR" Bezel Assembly	29a	N/A	46060	46060	47610
"VCR" Upper Front Panel with/Insulation	29b	N/A	46035	46035	47585
"VCR" Lower Front Panel	29c	N/A	46040	46040	47590
"VCR" Casing Upper Trim	29d	N/A	46045	46045	47595
"VCR" Casing Lower Trim	29e	N/A	46047	46047	47596
Cozy Logo Emblem	N/A	80006	80006	80006	80006
Clips, for Cozy Emblem	N/A	80007	80007	80007	80007
Casing Base Assembly	30	45175	45640	46460	47180
Leg Levellers (4 per heater)	31	80009	80009	80009	80009
Heat Exchanger, Closed Front	32	45200	45675	46500	47200
Heat Exchanger, Radiant Front	32	N/A	46100	46825	47700
Heat Exchanger Spacer	N/A	N/A	45845	45845	45845
Rear Leg, Heat Exchanger	32A	N/A	45760	45760	45760
Draft Diverter Assembly	33	45300	45785	46560	47295
Gusset	34	*45195	*45195	*45195	*45195
Radiant Glass Panel, "VCR" Series	35	N/A	*80079	*80079	*80079
Radiant for "VCR" Series (5 per htr.)	36	N/A	80073	80073	80073
Radiant Support Rail "VCR" Series	37	N/A	*46160	*46160	*46160
Piezo Ignitor	38	80016	80016	80016	80016
Piezo Wire	39	80127	80128	80129	80129
Valve Support Bracket	41	45860	45860	45860	45860
Lighting Instructions	N/A	91267	91267	91267	91267
BLOWER PARTS					
CHB-3 BLOWER					
Speed Control Switch w/Knob & Dec	42		70111	\$26.70	
Fan Switch	43		80253	\$7.40	
Fan Switch Bracket	44		47840	\$3.80	
Power Cord	45		80202	\$4.20	
Motor Wiring Harness	46		80256	\$3.80	
Blower/Motor Assembly	47		80251	\$56.30	
Blower Gasket - 7-1/4"	N/A		*80257	\$1.20	
Blower Gasket - 4-5/8"	N/A		*80258	\$1.20	
Junction Box Assembly	48		47850	\$12.70	
Junction Box Cover	49		47870	\$5.10	
Blower Nozzle Assembly	50		47820	\$13.30	
Mounting Bracket	51		47835	\$2.20	
Blower Platform Assy. (70 only)	N/A		47335	\$16.40	

MARCH 2005

Revised 12/03

*2 Required