






Illustrated Parts








Order by Part Number

Stopper - Plastic
186589 




Removable Splash Guard
1016 

Sink Flange - Polished Stainless
1017 

Mounting Assembly Kit - 1824

Fiber Gasket 
 Backup Flange 
 Screws (x3) 
 Mounting Ring 
 Snap Ring 
 Cushion Mount 
 Lower Mounting Ring 

Drain Elbow Kit - 1026

Rubber Gasket 
 Screws 
 Drain Elbow 



Replacement Power Cord Kit
1024 

Garbage Disposals

MODEL GXP50c

Other Available Accessories



Air Switch Remote Controller

- Installs into existing sink hole to operate disposer with plunger air switch.
- Perfect application for island countertops or where electrical switch is unavailable.
- No wiring connections or code restrictions.

Air Switch Base Unit

| Air Switch Remote Controller | ARC-4200 |
|--|-------------|
| Additional Air Switch Button Finish Options: | |
| Chrome | AS-4201-CH |
| Satin Nickel | AS-4201-SN |
| Polished Brass | AS-4201-BR |
| White | AS-4201-WH |
| Almond | AS-4201-AL |
| Biscuit | AS-4201-BIS |

Optional:

Dishwasher Connector Kit
1023 

Unjamming Wrench
1037 