


# Replacement Parts

## Geberit Hands-Free Sigma10 and Mambo Actuator


115.891 115.890 115.856


Actuator Dimensions: 9.7" x 6.5" (24.6 cm x 16.4 cm)



Item	Model No.	Description
1	1	241.150.00.1 Lifting device with servo-motor for WC-control
2	2	241.303.00.1 Protection plate for WC-control Sigma10 and Mambo
3	3	241.476.00.1 Electronic sensor for WC-control
3.1	3.1	242.870.00.1 Battery housing (only for 115.891)
4	4	242.871.00.1 Mounting frame for WC-control
5	5	242.781.SN.1 IR actuator plate for WC-control Sigma10 and Mambo
5.1	5.1	241.478.00.1 IR window with adapter for WC-control Sigma10 and Mambo
6	—	2 batteries, LR20 (standard) "D" cells
7	7	115.861.00.1 Control installation set
7.1	7.1	241.149.00.1 Power supply unit
7.2	7.2	241.161.00.1 Cover for housing for electric socket
7.3	7.3	241.302.00.1 Housing for electric socket
8	8	241.831.00.1 Extension mains cable
9	9	242.975.11.1 Flush valve crown
	10	243.356.00.1 Lifting device WC-control 2x4 (2016 version)
	11	242.425.00.1 Mounting frame for Mambo
	12	241.877.00.1 Fastening set for mounting frame. Tool free assembly.

### 115.891 (Battery/DC), 115.890 (AC), 115.856 (AC)



Products marked with  comply with the American Disabilities Act (ADA) when installed per the requirements of the latest ADA Accessibility Guidelines (ADAAG) and/or ICC/ANSI A117.1.