

ELECTRONIC TANK TOP UNIT

P/N: 7381559-400.XXX0A

- Electronic tank top assembly with batteries, no cleaning solution

TO REMOVE TANK TOP:

- Lift the tank lid and turn the locking screws a quarter turn counterclockwise to the unlock position then lift tank top upwards (see figure 1)

TO RE-INSTALL:

Note: If this is a new tank top, first remove the orange locking pins underneath

- Place the electronic tank top unit on top of the tank
- Turn the locking screws a quarter turn clockwise to the locking position and close the tank lid.

Note: The low indicator light works with new ActiClean Cleaning cartridges only.




FIGURE 1