



## Gas Vent Support Collar & Hardware



- For use with field fabricated support plates and support plates for odd sized openings.

| SIZE | ORDER # | STOCK #   | A      |
|------|---------|-----------|--------|
| 3"   | 3BVVSC  | 810017790 | 3 5/8" |
| 4"   | 4BVVSC  | 810017882 | 4 5/8" |
| 5"   | 5BVVSC  | 810017965 | 5 5/8" |
| 6"   | 6BVVSC  | 810018058 | 6 5/8" |


## Gas Vent Roof Support



- Used to support Type B gas vent pipe at roof level.
- Can be used when DuraConnect II is installed in attic space.

| SIZE | ORDER # | STOCK #   | A      | B       |
|------|---------|-----------|--------|---------|
| 3"   | 3BVS    | 810017794 | 3 5/8" | 14 3/4" |
| 4"   | 4BVS    | 810017886 | 4 5/8" | 15 3/4" |
| 5"   | 5BVS    | 810017969 | 5 5/8" | 16 3/4" |
| 6"   | 6BVS    | 810018062 | 6 5/8" | 17 3/4" |

## Gas Vent Firestop Spacer



- Used to protect combustible materials where pipe passes through a ceiling or wall
- Extended bottom flange

| SIZE | ORDER # | STOCK #   | A       | B       |
|------|---------|-----------|---------|---------|
| 3"   | 3BVFS   | 810017795 | 5 1/2"  | 5 1/2"  |
| 4"   | 4BVFS   | 810017887 | 6 1/2"  | 6 1/2"  |
| 5"   | 5BVFS   | 810017970 | 7 1/2"  | 7 1/2"  |
| 6"   | 6BVFS   | 810018063 | 8 1/2"  | 8 1/2"  |
| 7"   | 7BVFS   | 810018132 | 9 1/2"  | 9 1/2"  |
| 8"   | 8BVFS   | 810018200 | 10 1/2" | 10 1/2" |