




**NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.**

Ref. No.	Catalog No.	Description	Ref. No.	Catalog No.	Description
—	69982	226 Soil Pipe Cutter Assembly	16	71812	Center Arm
1	70437	Ratchet	17	71782	Bronze Thrust Washer
2	71772	Feed Screw w/Knob (Includes Nut & Washer)	18	71777	Steel Thrust Washer
3	33605	Hook Assembly	19	71792	Pivot Nut
4	33635	Spacer Wheel	20	83120	Hex Screw $\frac{3}{8}$ " x 16 x $1\frac{3}{4}$ " (2)
5	71797	Left Arm	21	71822	Plug 1.25" SQ.
6	33685	Retaining Ring (4)	22	71817	Handle
7	33675	Chain Ring	23	79985	Stop Nut $\frac{3}{8}$ " - 16 (2)
8	33650	Pin	24	71832	Handle Grip
9	44312	Hex Head Screw $\frac{5}{8}$ " - 18 x $1\frac{3}{4}$ "	25	72032	Warning Label
10	33670	Chain Assembly	26	71827	Nut $\frac{5}{8}$ " - 18
11	33645	Pin	27	71787	Right Arm
12	33220	Cutter Wheel	28	33680	Cutter Pin
13	71807	Pivot Pin	29	33220	Cutter Wheel
14	18978	Nut Lock, $\frac{5}{16}$ " - 18	30	33665	Chain Extension Assembly
15	83890	Nut, $\frac{1}{2}$ " - 20 (Old Style)			
	18983	Washer, M8			
	27402	Flat Washer $\frac{1}{4}$ " I.D. (Old Style)			