



SERVICE PARTS LIST

BULLETIN NO.
54-06-2135

SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS		REVISED BULLETIN	DATE
M18™ ROCKET™ LED TOWER LIGHT/CHARGER			Nov. 2016
CATALOG NO.	2135-20	STARTING SERIAL NO.	H36A
		WIRING INSTRUCTION	

EXAMPLE:
Component Parts (Small #)
Are Included When Ordering
The Assembly (Large #).

NOTE:
For detailed explanation of LED Light Assemblies 77, 78 and 79, see page 2.

NOTE:
For Clamp Assemblies 84 and 85, see service detail to the right.

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
1	-----	Base w/ Electronics and Outlet	(1)
2	23-33-0550	AC Outlet Door	(1)
3	40-50-2010	AC Outlet Door Spring w/ Pin	(1)
10	44-14-0240	Wire Leg Linkage	(3)
11	-----	Power Cord with Ferrite Bead	(1)
12	44-04-0105	Support Leg	(3)
13	42-78-0205	Main Support Column	(1)
16	44-60-1655	Leg Support Pin	(3)
17	43-62-0105	Switch Handle Support (less switch)	(1)
20	45-60-0055	Large Tube Base Support	(1)
23	45-76-0116	Large Tube	(1)
30	42-40-0006	Small Tube Slide Bushing	(1)
31	45-76-0126	Small Tube	(1)
36	42-52-0007	LED Mounting Cap Support with Nut	(1)
41	06-82-0069	M3.0 x 30 Pan Hd. ST T-10 Screw	(3)
44	45-56-0110	Sliding Handle Guide Strap	(2)
46	12-20-2317	Service Nameplate	(1)
48	42-36-0027	M18™ Leg Support Bracket	(1)
50	06-82-0019	3.5 x 14 Pan Hd. ST T-15 Screw	(26)
51	06-82-0059	M4.0 x 27.5 Pan Hd. T-20 Machine Screw	(4)
52	06-82-0039	M3.5 x 12 Pan Hd. ST T-15 Screw	(14)
54	44-40-0485	M4 Nut	(4)
56	45-88-0202	Washer	(1)
57	06-75-0006	M6 Hex Socket Machine Screw	(1)
58	06-82-0029	3.5 x 20 Pan Hd. ST T-15 Screw	(16)
76	23-26-0105	Complete LED Light Assembly	(1)
76a	-----	LED Light Assembly Base Housing	(1)
77	23-26-0110	LED Left Light Assembly	(1)
77a	-----	LED Left Light Lower Housing	(1)
78	23-26-0115	LED Middle Light Assembly	(1)
78a	-----	LED Middle Light Lower Housing	(1)
79	23-26-0120	LED Right Light Assembly	(1)
79a	-----	LED Right Light Lower Housing	(1)
80	44-06-0055	LED Lens Assembly (Set of 1)	(1)
80a	-----	M3.0 x 12 Pan Hd. ST T-10 Screw	(4)
80b	-----	LED Lens Cover	(1)
80c	-----	LED Lens Gasket	(1)
80d	-----	LED Lens	(1)
80e	-----	LED Lens Plate	(1)
82	42-52-0505	LED Mounting Cap w/ Washers and Screws	(1)
82a	05-83-0025	4 x 11 Round Hd. Phillips Machine Screw	(8)
82b	05-90-0055	Spring Washer	(8)
82c	05-90-0065	Washer	(8)
82d	-----	Mounting Cap	(1)
83	31-55-0075	LED Shroud Assembly	(1)
83a	-----	Shroud Support - Right	(1)
83b	-----	Shroud Support - Left	(1)
83c	-----	LED Shroud	(1)
83d	10-20-1018	Warning Label - Left	(1)
83e	10-20-1019	Warning Label - Right	(1)
84	31-17-0090	Small Tube Clamp Assembly	(1)
84a	44-10-0685	Clamp Lever	(2)
84b	45-22-0180	Upper Sleeve	(1)
85	31-17-0095	Large Tube Clamp Assembly	(1)
85b	45-22-0185	Lower Sleeve	(1)
88	31-44-1035	Sliding Handle Assembly	(1)
89	-----	Switch Box Assembly	(1)
91	34-40-0355	O-Ring	(1)
92	34-40-0357	O-Ring	(1)
93	40-50-0255	Tension Spring	(1)
94	42-36-0195	Retaining Bracket	(1)
95	45-22-0165	Sleeve	(1)
96	06-82-0180	M2.5 x 20 Torx Round Hd. Screw	(3)
	10-20-2011	Warning Label (not shown)	(1)
	48-55-2135	Soft Carrying Bag (not shown)	(1)

Adjustments may be needed to Clamping Assemblies 84 and 85 to prohibit sliding when latched. Tighten or loosen adjustment screw and flip clamp lever to the feel. If clamping the lever seems too difficult **do not force lever**. Screw should be loosened slightly and try securing the lever again. If lever seems too loose, tighten screw slightly and flip clamp lever to the feel.

How to Determine the Individual LED Light Assemblies

